



外形安装尺寸 Mounting Dimension Sheets-overview

R87




电机需方配时或配特殊电机时需加联接法兰
When equipping the user's motor or the special one, the flange is required to be connected.




RF87


Φ 300




R..S87



Φ 350



R..87R57



注：其余尺寸见相应的结构形式
Note: For other values please refer to the opposite structure

Y2电机机座号 Motor size 功率/4P Power/(kW)	80	90S	90L	100	112M	132S	132M	160M	160L	180M	180L
L3	246	280	304	350	380	425	461	524	547	583	616
G	175	195	195	215	240	275	275	330	330	380	380
L2	86	86	86	71	71	101	101	126	126	126	126

注：“R..”表示R、RF

Note：“R..”mean R、RF