

# 外形安装尺寸 Mounting Dimension Sheets-overview

K

### K97

### KAB97

### KA97

### KAZ97

### KF97

### KAF97

### KAT97

防转臂C面安装  
C side of torque-arm

防转臂D面安装  
D side of torque-arm

### K..S97

### K..97R57

电机需方配或配特殊电机时需加联接法兰  
When equipping the user's motor or the special one, the flange is required to be connected.

注:其余尺寸见相对应结构形式  
Note: For other values please refer to the opposite structure.

Y2电机座号 Motor size	90S	90L	100	112M	132S	132M	160M	160L	180M	180L	200
功率/4P Power/(kW)	1.1	1.5	2.2 3.0	4.0	5.5	7.5	11	15	18.5	22	30
L3	280	304	315	334	425	461	524	547	555	588	652
G	195	195	215	240	275	275	330	330	380	380	420
L2	86	86	101	101	101	101	126	126	126	126	132

注:1.KA, KF, KAF, KAZ壳体为通用件,安装尺寸均可相互参照。 2."K.."表示K, KA, KF, KAF, KAZ, KAB。  
Note:1.The housings of KA, KF, KAF, KAZ are common parts.The mounting dimensions may consult each other. 2."K.."mean K, KA, KF, KAF, KAZ, KAB.